



TV-PC85 VGA CONVERTER USER MANUAL



1.Introduce

What can I use PC TV Encoder for?

- A. Share computer Data to everyone.



- B. Play different format Video clips on pc (such as *.rm,divX,...) which DVD can't play. Convert the Video from PC to TV set,and, enjoy it!



- C. Too small Monitor to play TV Game? Just convert to TV Set.




p/n:874-00067

2.In Package

You can find accessories in package


- | | |
|--------------------|-----|
| 1) PC TV Encoder | x 1 |
| 2) USB Power Cable | x 1 |
| 3) VGA Cable | x 1 |
| 4) AV Cable | x 1 |
| 5) S-VHS Cable | x 1 |
| 6) User Manual | x 1 |

3.Install



4.Settings


■ 4-1 Connectors




■ 4-2 Switch setting for Video Standard



■ 4-3 Control Panel





1. Press "MENU" to display OSD of Settings on the screen. (See right picture)
2. Use "UP" or "DOWN" keys to select setting.
3. Use "LEFT" or "RIGHT" keys to tune status of the setting.


■ 4-4 OSD Panel

Press "MENU" activate the OSD,

Use Direction keys UP/DOWN to select different options.

Use Direction keys LEFT/RIGHT to change setting.

Press "MENU" again to confirm setting.



USE left and right key to Adjust screen width

Adjust screen High

Adjust Brightness

Adjust Contrast

Adjust Hue


Adjust Saturation

Adjust picture flick


Adjust Sharpness

Adjust Sharpness

Set Horizontal strips



Set Clear



■ 4-5 Graphic Card setting

PC(IBM Computer compatible)

Graphic Card Resolution	Refresh setting
640 x 480	60/72/75/85 HZ
800 x 600	56/60/72/75/85 HZ
1024 x 768	60/72 HZ

Mac (Apple Computer)

Graphic Card Resolution	Refresh setting
640 x 480	66 HZ
832 x 624	75 HZ